

HC16P012A0-8PIN-引脚图

HC16P012A0_SOP8


| | | | |
|-----------------------|---|---|------------------------------------|
| VDD | 1 | 8 | VSS |
| CMPP/OSCI/PWM2/PORTB5 | 2 | 7 | PORTB0/INT0/PGC/T1CKI/PWM2/CO/TKN0 |
| CMPP/OSCO/PWM1/PORTB4 | 3 | 6 | PORTB1/PGD/PWM1/CMPN/TKN1 |
| VPP/PWM0/PORTB3 | 4 | 5 | PORTB2/T0CKI/PCK/PWM0/CMPP/TKN2 |

HC16P012A0-6PIN-引脚图


HC16P012A0_SOT23-6

| | | | |
|------------------------------------|---|---|---------------------------|
| TKN0/PORTB0/INT0/PGC/T1CKI/PWM2/CO | 1 | 6 | PORTB1/PGD/PWM1/CMPN/TKN1 |
| VSS | 2 | 5 | VDD |
| TKN2/PORTB2/T0CKI/PCK/PWM0/CMPP | 3 | 4 | VPP/PWM0/PORTB3 |

HC16P012A0-8PIN-转接板接线图



HC16P012A0-6PIN-转接板接线图



注意事项

- 1、VPP 需要串接 240 欧姆电阻